




**FIG. 1**




**FIG. 2**



**FIG. 3**




**FIG. 4**




Note : \* If Receiver wants to receive the call initiator's AVATAR for displaying during idle periods and for storing into the PM for future use, one time transmission can be inserted this time slot

**FIG. 5**




**FIG. 6**




Note : \*\* The AVATAR displayed at the receiver during the idle period can be the one received from the call initiator or the one fetched from the PM

**FIG. 7**



**FIG. 8**



**FIG. 9**